



Taha Kimia TajhizCo.



Core Lab



# Oil Sample Restoration 4 Cylinders Datasheet

Reservoir Fluid Analysis-PVT\Sample Preparation



## OSR4 - Oil Sample Restoration



Front side



Back side

### General Features

ST Sample Restoration System ensures proper mixing of sample fluids thanks to heating jackets and controllers. Cylinders are placed in heating jackets on each side of the apparatus. Temperature can be adjusted and the motorized rocking system allows stirring of the cylinders. Of course, number of cylinders can be adjustable upon customer request. This apparatus can be delivered upon request with adaptors to fit any diameter of bottles present on the market.

ST Sample Restoration System is composed of following items:

- Wheeled cart to move easily the equipment anywhere.
- Heating jackets placed around cylinders to ensure a constant temperature
- Electric cabinet to control the apparatus
- Cylinders (optional)

Specifications	
Working Temperature	Up to 200°C
Number of Cylinders	Adjustable upon request
Speed Agitation	Variable
Cylinder Size	Adjustable upon request