



Taha Kimia Tajhiz Co.



OFITE

BD10 Power Feed Trim Saw Datasheet

Core Preparation / Slabbing-Trimming-Grinding



BD10 Power Feed Trim Saw

The Barranca Diamond BD10 power feed trim saw with 1/3 HP motor is perfect for cutting facet material, opals and rock slabs of all types. Cuts slabs easily with the 15-3/8" x 19-1/2" work surface.

Features

- All cast aluminum tank, table, blade guard and power feed box
- Hinged table top for ease of sludge/oil and blade removal
- Vertical rock vise clamping system
- Vise rotates out of the way for manual trim saw use
- Sealed blade arbor-bearing assembly
- PETG high-impact, copolymer hood
- Brass clutch plate engage/disengagement system
- Single speed (3/16" per minute feed rate) power feed system
- Mounted on a 1/2" polypropylene base
- Professional Lapidary Diamond Blade (10" x .040 x 5/8)
- Shipping weight 80 lbs. crated

Specifications

	Motor	Leason
	Horse Power	1/3
	Voltage*	110V/60Hz
	Amperage	5.8
	Motor RPM	1,725
	Blade Arbor	5/8"
	Blade Capacity	8" - 10"
	Depth of Cut: Manual Cutting	3"
	Depth of Cut: Power Feed Cutting	2 - 5/8"
	Max. Vise Opening	3 - 1/4"
	L x W x H (in)	27" x 17" x 19"
	L x W x H (mm)	686 x 432 x 483 mm
	Saw Weight	70 lbs.
	Part #	168787

*220Volt/50Hz Part # 169201

For more information
800.630.7682